Hotmaps Dispatch Module Documentation

Release 0.0.1

Jeton Hasani

Mar 02, 2021

Contents:

1	Getti	ng Started
	1.1	Workflow
	1.2	Things to consider
2	User	Guide
	2.1	The Web User Interface
	2.2	Button Section
		2.2.1 Short Description:
		2.2.2 Long Description:
		2.2.2.1 Download
		2.2.2.1.1 Worksheets
		2.2.2.2 Upload
		2.2.2.3 Run
		2.2.2.4 Reset
		2.2.2.5 Invest
	2.3	Notification Section with Peak Load and Missing Capacities – Information
		2.3.1 Short Description:
		2.3.2 Long Description:
		2.3.2.1 After pressing the Run Dispatch Model Button
		2.3.2.2 After Pressing the Download Button
		2.3.2.3 After Pressing the Upload Button
		2.3.2.4 After Pressing the Invest Button
		2.3.2.5 After Pressing the + Button in the Heat Producers and Heat Storage Tab 10
		2.3.2.6 After Pressing the \checkmark ADD Button in the Heat Generator Adding Section 1
		2.3.2.7 After Pressing the \checkmark - Button in the Sale-/Electricity Price Tab
		2.3.2.8 After Uploading a file in the Load Individual Data Tab
		2.3.2.9 After Pressing the \checkmark Save Button in the Load Individual Data – Tab
	2.4	Output Section
		2.4.1 Short Description: 1.
		2.4.2 Long Description:
	2.5	Data Section
		2.5.1 Heat Producers and Heat Storage – Tab
		2.5.1.1 Short Description:
		2.5.1.2 Long Description:
		2.5.1.2.1 Heat Generator Table
		2.5.1.2.2 Heat Storage Table

	2.5.1.2.3 Add new Heat Generator Section	17
	2.5.1.2.3.1 Available Heat Genrators	18
	2.5.1.2.3.2 Available types of boilers	18
	2.5.1.2.3.3 Available types of heat pumps	19
	2.5.1.2.3.4 Available types of CHP-Steam Extraction types	19
	2.5.1.2.3.5 Available types of CHP-Back Pressure types	20
	2.5.1.2.3.6 Technical Parameters – Tab	20
	2.5.1.2.3.7 Finance Parameters – Tab	21
	2.5.1.2.3.8 Model Parameters - Tab	22
	2.5.1.2.3.9 Coefficient of Performance, COP – Tab	23
2.5.2	Parameters – Tab	23
	2.5.2.1 Short Description:	23
2.5.3	Prices & Emission factors – Tab	24
	2.5.3.1 Short Description:	24
2.5.4	Radiation – Tab	25
	2.5.4.1 Short Description:	25
2.5.5	Temperature – Tab	27
	2.5.5.1 Short Description:	27
2.5.6	Electricity price / Sale Electricity price – Tab	27
	2.5.6.1 Short Description:	28
2.5.7	Heat Demand – Tab	29
	2.5.7.1 Short Description:	29
2.5.8	Load Individual Data – Tab	30
	2.5.8.1 Short Description:	30
	2.5.8.1.1 Upload External Data – Button	30
	2.5.8.1.2 Create Data – Tools	30
	2.5.8.1.3 Table	30
	2.5.8.1.4 Plot Area	30
	2.5.8.1.5 Modification Tools	31
	2.5.8.1.6 Saving Tools	31
	2.5.8.2 Long Description:	31
	2.5.8.2.1 Upload External Data	31
	2.5.8.2.2 Create Data Tool	32
	2.5.8.2.2.1 Dirichlet Distribution:	32
	2.5.8.2.2.2 Normal Distribution	33
	2.5.8.2.2.3 Linear Distribution	34
	2.5.8.2.3 Table and Plot Area	35
	2.5.8.2.4 Modification Tools	35
	2.5.8.2.5 Saving Tools	36

3 Indices and tables

CHAPTER 1

Getting Started

This Getting Started guide aims to get you using the Hotmaps-Dispatch-Application as quickly as possible

1.1 Workflow

- 1. Select a heat demand profile in the *Heat Demand Tab* or upload your own profile via the *Load Individual Data -Tab*
- 2. Set the yearly heat consumption of your region in the *Heat Demand Tab* or in the *Paramters- Tab*, by editing the Total Demand [MWh] input widget
- Add predefined *heat generators* or *heat storages* in the *Heat Producers and Heat Storage Tab* by pressing the
 + Button or *upload* custom generators via the Upload Power Plant Parameters Button
- 4. Set various prices, parameters, profiles, etc. or upload your own data and click on the Run Dispatch Model -Button
- 5. After 60 to 120 seconds the results are shown in the output section

1.2 Things to consider

- · Refreshing the page deletes all your progress
- Always save your progress by *downloading* the created structure
- After calculation is done *download* the result files
- Copy the link of the results if something occurs you can access your results within 2 hours (this saves you time)
- If you upload your own data, pay attention to the needed structure as described here and here
- Look up the heat *generator types* that are available when generating your custom structure outside the Application
- Don't forget to press the \checkmark Button in the Sale-/Electricity Price Tab, because only so changes take effect

- If the page doesn't respond for a long time or something else happened refresh the page and try again, if the issue is still present look up the *User Guide*, if you have still the issue please document all setting you set (which browser, parameters, data, etc. did you use)
- At last but not least, be patient...

CHAPTER 2

User Guide

The User Guide is the primary resource for documenting key concepts that will help you use the Hotmaps-Dispatch-Application in your work

2.1 The Web User Interface

The figure below shows the User Interface. At first glance, you can see that the Application is divided into four sections:

- 1. Button Section
- 2. Notification Section with Peak Load and Missing Capacities Information
- 3. Output Section



4. Data Section

In the following chapters, each section is described in detail.

2.2 Button Section



2.2.1 Short Description:

- In this Section, you can download the created structure to save your progress,
- You can upload your saved progress, or a custom structure into the Application,
- You can run the model you created,
- You can reset the view for better workflow or
- You can start an investment model

2.2.2 Long Description:



Download Power Plant Parameters

By pressing this button, the browser will try to download a file with the name *download_input.xlsx* that contains all the Information regarding heat producers and heat storages. The downloaded file has the following format (for uploading the same format must be specified): It has five worksheets:

2.2.2.1.1 Worksheets



The worksheets have following structure (columns):

• Heat Generators:

1	А	В	С	D	E	F	G	н	1	J	к	L
1		name	installed capacity (MW_th)	efficiency th	efficiency el	investment costs (EUR/MW_th)	OPEX fix (EUR/MWa)	OPEX var (EUR/MWh)	life time	renewable factor	must run [0-1]	type
2	0	Air Heat Pump	500	2.81	0	700000	2000	8.4	25	0	0	heat pump
3	1	heat boiler natural gas	200	0.99	0	150000	1100	0.8	20	0	0	boiler
4	2	Solar Thermal	172	0.8	0	550000	10000	0	20	0	0	Solar Thermal
4	2	Solar Inermal	1/2	0.8	0	550000	10000	0	20	0	0	SOI

• prices and emission factors:

	А	В	С	D
1		energy carrier	prices(EUR/MWh)	emission factor [tCO2/MWh]
2	0	ambient heat	0	1
3	1	electricity	0	0.8
4	2	gas. Biomass	62	1
5	3	gas/oil	47	0
6	4	natural gas	30	0
7	5	straw	22	1
8	6	various	20	1
9	7	waste	5	0.8
10	8	waste heat 20°	0	1
11	9	waste heat 40°	0	1
12	10	wood chips	22	1
13	11	wood pellets	36	1
14	12	radiation	0	0

• Data:

	Α	В	E			
1		CO2 Price [EUR/tC02]	Interest Rate [0-1]	Minimum Renewable Factor [0-1]	Total Demand[MWh]	
2	0	25	0.5	0	600000	

• Heat Storage:

 name
 Storage Capacity [MWh]
 Hourly Stoarge Losses [%]
 maximum unloading power [MWI]
 Inading efficiency
 unloading efficiency
 Investment costs for additional storage capacity [€/MWh]
 OPCK fix [€/MWh]
 Ufe Time [a]

 0
 5torage
 1000
 1
 80
 80
 0.55
 0.52
 60
 10000
 25

• Energy Carrier:

	А	В	С		
1		name	carrier		
2	0	Air Heat Pump	electricity		
3	1	heat boiler natural gas	natural gas		
4	2	Solar Thermal	radiation		

2.2.2.2 Upload

Upload Power Plant Parameters

By clicking this button, a pop up window will open and you will be able to upload a xlsx file. That overwrites the content of the web user interface. The file you upload **must** have the structure as described *before* in the long description of the download powerplant parameters -Button.

Consider following:

- You have to create a file that has the same names for the worksheets and columns
- The worksheet names are case sensitive

- The column names are case sensitive
- You must specify an index column starting with 0
- You can create maximum 13 energy carriers

Following heat generator types are available (type column in the Heat Generators worksheet)

Run Dispatch Model

By Pressing this button, the optimization will start. You will get a progress shown in the notification section. Depending on the structure you create the optimization will run for about 60 to 120 seconds. Please be aware that your browser might freeze at that time. After the solution is found the results are shown in the output section. You can download then the results via the *buttons* in the *notification section*. Also, if something gets wrong you will get information in the notification section. If unexpected errors occur please document and send detailed instruction to reproduce the error and send these instruction with a short problem description.



By pressing this button, the notification section and the output section will be cleared, and you will get a "fresh" view.



The Application is implemented as a linear program and can be used on the one hand as a pure dispatch model and on the other hand for investment planning (how much capacities to install) to cover a load profile with the minimum costs. If you enable this toggle button, it is important to specify the heat producers and heat storages by marking them (hold CTRL and left mouse click to select the desired generators and storages) for which an investment model should run.

2.3 Notification Section with Peak Load and Missing Capacities – Information



2.3.1 Short Description:

In this section, you will get information regarding the progress, the peak load, missing capacities and errors that occur.

2.3.2 Long Description:

In the following you will see some frequent messages (progress and error information) that might appear in the notification section.

2.3.2.1 After pressing the Run Dispatch Model Button

• Dispatch in progress, please be patient... This can take some time. Typically, also to browser can freeze when the calculation is done and the results are rendered in the browser

	Dignotoh in prograss, plassa ha patient	Pmax [MW]
Download Power Plant Parameters	Dispatch in progress, please be patient	363.73
Upload Power Plant Parameters		Missing Capacities [MW]
	(***)	0
Run Dispatch Model		
Reset View		
Invest		

• Calculation is Done With these buttons, you can download your results. It might happen that the page freezes after downloading, please be patient. We recommend also to save the link of these file right click on the buttons Copy Link (after 2 hours this links will not work but you can download the files directly if the page freeze and so save so your time)



• No Heat Generators available This will happen if you haven't specified and model from initial any heat generators wanted to start the the page.

	No Heat Generators aviable	Pmax [MW]
Download Power Plant Parameters		3637.33
Upload Power Plant Parameters		Missing Capacities [MW]
		3637.33
Run Dispatch Model		
Pecet View		
Reserview		
Invest		

• The installed capacities are not enough to cover the load This will be shown when you haven't specified enough MW to cover the peak load (see missing Capacities in the right sight of the notification section)

	The installed capacities are not enough to cover the load	Pmax [MW]
Download Power Plant Parameters		3637.33
Upload Power Plant Parameters		Missing Capacities [MW]
		3637.33
Run Dispatch Model		
Keset view		
Invest		

• Error: Problem proven to be infeasible or unbounded This happens typically when constraints cannot be met and can have a lot of reasons, its upon you to think about what could happen.

	Error: Problem proven to be infeasible or unbounded.	Pmax [MW]
Download Power Plant Parameters	·	363.73
Upload Power Plant Parameters		Missing Capacities [MW]
		0
Run Dispatch Model		
Reset View		
Invest		

• Error: Please specify the technologies for the investment model This is shown when enable investment planning select the heat generayou but you forgot to tors and heat storages to mark, with whom it should do an investment optimization

Download Power Plant Parameters	Error: Please specify the technologies for the invesment model !!!	Pmax [MW]
Upload Power Plant Parameters	Mark Heat Generators by pressing "CTRL" + "left mouse" Selection is marked yellow	Missing Capacities [MW]
Run Dispatch Model		0
Reset View		
Invest		

2.3.2.2 After Pressing the Download Button

•	Noth	ing	to	do	ownload	Ту	pically,	this	occurs	W	hen	you	wan	t to	do	wn-	
	load	the	init	ial	page,	to	download	you	need	to	add	first	а	heat	gener	ator	
		Download	Power Pla	nt Para	meters			Nothin	ig to download				Pma	x [MW]			
													36	37.33			
		Upload Po	ower Plant	t Param	eters								Missing Capacities [M			Ŋ	
													36	37.33			
		Rur	n Dispatch	Model													
			Reset Vie	EW													
			Invest														
			Invest														
											Download	done			F	'max [l	uvv]
					Download Pov	wer Plant P	arameters				Dominada donior					363.7	73
					Lipload Pow	er Plant Pa	rameters								N	lissing	Capacities [MW]
					opiodali om	er maner a	, and the second									0	
					Run D	ispatch Mo	del										
					R	eset View											
•	Dow	nlood d	lono			Invest											
-	DOW	moau (JUIE														

2.3.2.3 After Pressing the Upload Button

• Not a valid file to upload This is shown when you try to upload an filetype other then .xlsx

	Not a valid file to uploade	Pmax [MW]
Download Power Plant Parameters		363.73
Upload Power Plant Parameters		Missing Capacities [MW]
		0
Run Dispatch Model		
Reset View		
Invest		

• Fatal Error @ Update This is shown when your file you want to upload has not the needed structure.

Download Powe	er Plant Parameters	Fatal Error @ Update	Pmax [MW]	
Upload Power	Plant Parameters		Missing Capacities [MW]	
Run Disp	patch Model		3637.33	
Res	et View			
Ir	nvest			
	Download Power Plant Parameters	Upload done	Pmax [MW] 363.73	
1	Upload Power Plant Parameters		Missing Cap	acities [MW]
1	Run Dispatch Model		U	
	Reset View			
Upload Done	Invest			

2.3.2.4 After Pressing the Invest Button

• Mark Technologies by pressing "CTRL" + "left mouse" Rows are marked yellow As soon as you press the Invest Button you will see this Information in the notification section, it tells you that you need to specify for which generators and storages to do the investment planning. If you don't mark technologies you will get the message as described *here*

	Mark Technologies by pressing "CTRL" + "left mouse". Rows are marked	Pmax [MW]
Download Power Plant Parameters	yellow	3637.33
Upload Power Plant Parameters		Missing Capacities [MW]
		3637.33
Run Dispatch Model		
Reset View		
Invest		

2.3.2.5 After Pressing the + Button in the Heat Producers and Heat Storage Tab

waiting • This spinner is especially visible after pressing the + Button, typically the browser freezes, so be patient, the *add* is loading section



2.3.2.6 After Pressing the \checkmark ADD Button in the Heat Generator Adding Section



• Heat Generator ADDED

2.3.2.7 After Pressing the \checkmark - Button in the Sale-/Electricity Price Tab

				Download Power Pla	nt Parameters	I	Electricity pri	ice Data is set as Default	
				Upload Power Plan	t Parameters				
				Run Dispatch	Model				
				Reset Vie	ew				
• Sale-/Electricity pr	ice Data is s	set as Defau	lt	Invest					
Sale-/Electricity	price	Data	for	Heat	Generator	name	is	added	

•	Sale-/Electricity	price	Data	for	Heat	Generator	name	is	added
	Download Dower Dopt (Darameters		Electricity p	rice Data For Air	Heat Pump is added	Pma	ax [MW]	
		Parameters					30	53.73	
	Upload Power Plant Pa	arameters					Mis	sing Capaciti	es [MW]
							0		
	Run Dispatch Mo	odel							
	Reset View								
	Invest								

2.3.2.8 After Uploading a file in the Load Individual Data Tab

• Invalid Filetyp to load @ Loading External Data This is shown when you try to upload a filetype that is not

		Invalid Filetype to load @ Loading External Data	Pmax [MW]
	Download Power Plant Parameters		363.73
	Upload Power Plant Parameters		Missing Capacities [MW]
			0
	Run Dispatch Model		
	Reset View		
	Invest		
.xlsx or .csv			

•	Your file	f tha	ile t	has you	not uplo	er er	lough has	to	ues have	(please the	e specif structu	fy a ire	8760 as	value describ	es) Your ed <i>here</i>
		Davada					Your F	File has not e	nought val	ues (please	specify 8750 va	alues)	Pm	ax [MW]	
		Downio	ad Powe	er Plant Para	ameters								3	63.73	
		Uploa	d Power	Plant Param	neters								Mis	sing Capacit	ies (MW)
													0		
			Run Disp	patch Model											
			Res	et View											
			Ir	nvest											
•	Exteri	nal	Da	ta L	oaded	This	is	shown	when	the	external	Data	has	been	uploaded.
	E	Downloa	d Powe	r Plant Para	meters				Externa	l Data Load	led		t (max (MVV)	
														363.73	
		Unload	Power I	Plant Param	eters								N	lissing Capa	acities [MW]

Upload Power Plant Parameters
Run Dispatch Model
Invest

2.3.2.9 After Pressing the \checkmark Save Button in the Load Individual Data –Tab

• External Data name added to Profile as name_1 This is shown after adding a custom data to the profiles as de-

		External Data individual added to Radiation as individual 1	Pmax [MW]
	Download Power Plant Parameters		363.73
	Upload Power Plant Parameters		Missing Capacities [MW]
			0
	Run Dispatch Model		
	Reset View		
comited have	Invest		
scribed nere			

• n_th/COP - External Data added to Heat Generator name This is shown after adding a custom data for the thermal efficiency to a heat generator as described *here*

	n th/COP - External Data added to Air Heat Pump	Pmax [MW]				
Download Power Plant Parameters	-	363.73				
Upload Power Plant Parameters		Missing Capacities [MW]				
		0				
Run Dispatch Model						
Reset View						
Invest						
Invest						

2.4 Output Section

2.4.1 Short Description:



2.4.2 Long Description:

2.5 Data Section

2.5.1 Heat Producers and Heat Storage – Tab

Heat Producers and Heat Storage Adding Parameters Prices & Emission factors Profiles Load Individual Data	
# Instance efficiency if Investment costs (EURAMV_Ib) OPEX fsr (EURAMVb) OPEX var (EURAMVb) Me time renewable factor	must run [0-1]
Heat Generator Table	
HEAT STORAGES * name Storage Capacity (MMh) Hourly Stoarge Losses [5] maximum unloading power (MM) Institute bading power (MM) loading efficiency unloading efficiency Investment costs for additional storage capacity (EMMh) OPEX fs	< (G/MV/h] Life Time (a)
Heat Storage Table	

2.5.1.1 Short Description:

In this Tab, the *created* or *uploaded* heat generator and heat storage data is shown in two tables (heat storage table and heat generator table). The above picture shows the initial page (no heat generators and no heat storages are defined).

Please notice that it is possible to edit the values in the tables.

By pressing the + Button you will be navigated to the *Adding Tab*, for adding new heat generators or *heat storages*, pops up between the button section and the output section (see picture below) *.

• Section After Pressing + Button in the *Heat Generator Table*

Heat Producers and Hea	t Storage	Adding	Parameters	Prices & Emission fac	tors	Profiles	Load Individual Data
Add Heat Generators	Add Heat St	torages					
Add Heat Generator: heat pump		T					
Select a heat pump: heat pump - High Temp	erature -Geo 1	Thermal (6	60°C) ▼				
Technical Parameters	Coefficien	t of Perfor	mance, COP	Finance Parameters	Model	Parameters	
Energy Carrier ambient heat		T	Name heat pump -	High Temperature -Geo T	hern		
Thermal Efficiency 48.67			Electrical Effic	iency			
✓ ADD ★ CANCEL							

• Section After Pressing + Button in the *Heat Storage Table*

Heat Producers and Hea	t Storage	Adding	Parameters	Prices & Emission factors	Profiles	Load Individual Data
Add Heat Generators	Add Heat	Storages				
Select a Heat Storage:						
default heat storage		•				
Technical Parameters	Finance	Parameters	Model Parar	neters		
name			Storage Capaci	ty [MWh]		
default heat storage			0			
maximum loading powe	r [MW]		maximum unloa	ding power [MW]		
80			80			
loading efficiency: 0.95			unloading efficie	ency: 0.52		
✓ ADD ★ CANCEL						

2.5.1.2 Long Description:

2.5.1.2.1 Heat Generator Table

HE	HEAT GENERATORS 💽									
#	name	installed capacity (MW_th)	efficiency th	efficiency el	investment costs (EUR/MW_t	II OPEX fix (EUR/MWa)	OPEX var (EUR/MWh)	life time	renewable factor	must run (0-1)
(Air Heat Pump	100	48.67	0	700000	2000	8.4	25	0	0
	Boiler	500	0.85	0	800000	0	5.4	20	0	0
	CHP Steam Extraction Wo	200	0.64	0.29	4000000	29000	3.9	30	0	0
	waste treatment	500	0.98	0	1200000	54000	5.6	20	0	0
4	Solar Thermal	300	0.8	0	550000	10000	0	20	0	0

Your *added* (by pressing the + Button) or *uploaded data* of heat generators is shown here. You have the opportunity to change the values of the table *.

These parameters can also be changed via *uploading*. Therefor you have to create an excel sheet with the structure as described *here*. Then the parameters must be specified in the *Heat Generators worksheet*.

Format, unit and description of the Heat Generators Table

*Caution: In this table, it is not possible to change the heat generators *type* or *energy carrier*. The type is either defined by the *type column* in the *Heat Generators* worksheet when uploading power plant parameters or internally by adding from the user interface in the *Add new Heat Generator Section*. The same applies for the energy carriers, they can only be adapted via uploading an excel file (*energy carrier* worksheet) or via the internal *adding section*.

2.5.1.2.2 Heat Storage Table

# name Storage Capacity (M/M) Hourty Storage Losses (%) maximum unoading power (M maximum loading efficiency unloading efficiency loading efficiency <thlimatica< t<="" th=""><th colspan="7">HEAT STORAGES</th></thlimatica<>	HEAT STORAGES										
0 Storage 1000 1 80 80 0.95 0.52 60 10000 25	#	name	Storage Capacity [MWh]	Hourly Stoarge Losses [%]	maximum unloading power [M	maximum loading power [MW]	loading efficiency	unloading efficiency	Invesment costs for additional	OPEX fix (€/MWh)	Life Time [a]
	(Storage	1000	1	80	80	0.95	0.52	60	10000	25
1 default near storage 5000 1 200 200 0.8 0.8 60 10000 25		default heat storage	5000	1	200	200	0.8	0.8	60	10000	25

You have the opportunity to change the values of the table *. These parameters can also be changed via *uploading*. Therefor you have to create an excel sheet with the structure as described *here*. Then the parameters must be specified in the *Heat Storage worksheet*.

Format, unit and description of the Heat Storages Table

*Caution: Please be aware that only one heat storage is available, e.g. if you don't upload others only this storage will be editable. The + Button for heat storages does nothing, the implementation is in progress and in future this feature will become available.

Add Heat Generator:			
heat pump	~		
Select a heat pump:			
heat pump - High Temperature -G	o Thermal (60°C) 🗸 🗸		
Coefficient of Performance, COP	Technical Parameters	Finance Parameters	Model Parameters
Return Temperature	Inlet Temperature	9	
40°C	✓ 70°C		~
COP			
48.67			
✓ ADD ¥ CANCEL			

2.5.1.2.3 Add new Heat Generator Section

By pressing the + Button in the *Heat Generators Table* the above section pops up (please be patient this will take some time). All heat generators have the three red marked tabs in common, only for heat pumps an extra tab is shown (Coefficient of Performance, COP)

The picture below shows you all predefined heat generator types, that means by selection one of these, predefined values are loaded. You can see and edit the values in the *Technical Parameters Tab* and in the *Finance Parameters Tab*, but you can also change them in later in the *Heat Generator Table*. (after pressing \checkmark ADD)

2.5.1.2.3.1 Available Heat Genrators

Add Heat Generator:		
heat pump	~	
heat pump		
boiler		
CHP Steam Extraction	n (00 C)	
CHP Back Pressure		
waste treatment	ical Parameters Finance Parameters	Model Parameters
Solar Thermal		
Power To Heat	Flow Temperature	
Waste Heat	70°C	~
Geo Thermal		
СОР		
48.67		
✓ ADD		

2.5.1.2.3.2 Available types of boilers

Add Heat Generator:	
boiler ~	
Select a boiler:	
heat boiler natural gas 🗸 🗸	
heat boiler natural gas	
heat boiler wood chips heat boiler wood pellets	ers Model Parameters
heat boiler straw	Name
heat boiler electricity natural gas	heat boiler natural gas
Thermal Efficiency	Electrical Efficiency
1.03	0.0
✓ ADD ¥ CANCEL	

2.5.1.2.3.3	Available	types of	f heat	pumps
-------------	-----------	----------	--------	-------

Add Heat Generator:		
heat pump 🗸		
Select a heat pump:		
heat pump - High Temperature -Geo Thermal (60°C)	~	
heat pump - High Temperature -Geo Thermal (60°C)		
heat pump - Default	s Finance Parameters	Model Parameters
heat pump - River 5°C		
heat pump - River 10°C		
40°C	70°C	~
COP		
48.67		
✓ ADD ¥ CANCEL		

2.5.1.2.3.4 Available types of CHP-Steam Extraction types

Add Heat Generator:				
CHP Steam Extraction				
Select a CHP Steam Extraction:				
CHP-SE steam turbine (medium) wood chips				
CHP-SE steam turbine (medium) wood chips				
CHP-SE steam turbine (small) wood chips	arameters			
CHP-SE steam turbine (medium) straw				
CHP-SE steam turbine (small) straw				
CHP-SE waste treatment waste	im Extraction			
CHP-SE CC gas turbine/ steam extraction turbine gas/oil				
Thermal Efficiency	Electrical Efficiency			
0.64	0.29			
✓ ADD CANCEL				

2.5.1.2.3.5 Available types of CHP-Back Pressure types

Add Heat Generator:	
CHP Back Pressure	
Select a CHP Back Pressure:	
CHP-BP stirling engine gas. Biomass	~
CHP-BP stirling engine gas. Biomass	
CHP-BP spark ignition natural gas	I Parameters
CHP-BP spark ignition gas. Biomass	
CHP-BP CC gas turbine/ back-pressure turbine gas/oil	
gas. Biomass	CHP Back Pressure
Thermal Efficiency	Electrical Efficiency
0.58	0.2
✓ ADD ¥ CANCEL	

2.5.1.2.3.6 Technical Parameters – Tab

Add Heat Generator:				
heat pump	~			
Select a heat pump:				
heat pump - Default		~		
Coefficient of Performance, COP	Technical F	Parameters	Finance Parameters	Model Parameters
Energy Carrier		Name		
ambient heat	~	heat pum	p - Default	
Thermal Efficiency		Electrical E	fficiency	
5.01		0.0		
✓ ADD ★ CANCEL				

- Here you can select the energy carrier with witch the heat generator is fired. You can define a name and set the thermal and electrical efficiency. For heat pumps the input for Thermal Efficiency is disabled, because

it is defined via the *Coefficient of Performance*, COP - Tab. Each *heat generator* has predefined values that are shown here. You can and should change them.

Select a Heat Storage:		
default heat storage	•	
Technical Parameters	Finance Parameters	Model Parameters
name		Storage Capacity [MWh]
default heat storage		0
maximum loading power [N	(WN)	maximum unloading power [MW]
80		80
loading efficiency: 0.95		unloading efficiency: 0.52
✓ ADD ★ CANCEL		

- Here you can define the technical parameters for your heat storage

2.5.1.2.3.7 Finance Parameters – Tab

•

Add Heat Generator:			
heat pump	~		
Select a heat pump:			
heat pump - Default	~		
Coefficient of Performance, COP	Technical Parameters	Finance Parameters	Model Parameters
investment costs (EUR/MW_th	life time (a)		
700000	25		
OPEX fix (EUR/MVVa)	OPEX var (E	:UR/MWh)	
2000	8.4		
✓ ADD ★ CANCEL			

- Here you can see and change predefined values of financial parameters for selected heat generator.

Select a Heat Storage:		
default heat storage	•	
Technical Parameters	Finance Parameters	Model Parameters
Invesment costs for additio [€/MWh]	onal storage capacity	
60		
OPEX fix [€/MWh]		
10000		
Life Time [a]		
25		
✓ ADD ★ CANCEL		

- Here you can set the financel Paramters for your heat storage.

2.5.1.2.3.8 Model Parameters - Tab

Add Heat Generator:			
heat pump	~		
Select a heat pump:			
heat pump - Default	~		
Coefficient of Performance, COP	Technical Parameters	Finance Parameters	Model Parameters
Must Run			
Must Run Renewable Factor: 0			
Must Run Renewable Factor: 0			
Must Run Renewable Factor: 0 Installed Capacity: 0			
Must Run Renewable Factor: 0 Installed Capacity: 0			

- In this Tab, you can set the orange toggle Button Must Run, that mean that this heat generator must run all the time with 100% of its capacity (for more details see *here*) With one slider, you can set a renewable factor (values from 0 to 1, more details see *here*) and with the other you can set the installed capacity of your heat generator (values from 0 to *Pmax*,-Peak Load of the selected Heat Profile)

Select a Heat Storage:	
default heat storage	
Technical Parameters Finance Parameters	Model Parameters
Hourly Stoarge Losses [%]: 1	
ADD * CANCEL	

- In this Tab, you can set heat storage losses, please specify losses because if losses are zero it can happen that the storage is loading and unloading at the same time

2.5.1.2.3.9 Coefficient of Performance, COP – Tab

Coefficient of Performance, COP	Technica	al Parameters	Finance Parameters	Model Parameters
Return Temperature		Inlet Temperat	ure	
40°C	~	70°C		~
COP				
48.67				
✓ ADD CANCEL				

Only heat pumps have this additional tab. Here you can select an Inlet-and-Return-Temperature and based on that selection a COP is defined. In the *Technical Parameters Tab* the COP value is inserted into the thermal efficiency input widget (the widget itself is disabled, meaning you cannot edit the value here, but you can change it later in the *heat generators table*)

2.5.2 Parameters – Tab

He	at Producers and Heat Storage	Adding	Parameters	Prices & Emission factors	Profiles Load Individual D	ata 🗸	
#	# CO2 Price (EUR/tC02) Interest Rate (0-1)			Minimum Renewable Factor (0-1)	Total Demand[MWh]		
0	0 25		0.5		0	6000000	

2.5.2.1 Short Description:

In this tab, you can change following parameters

These parameters can also be changed via *uploading*. Therefor you have to create an excel sheet with the structure as described *here*. Then the parameters must be specified in the *data worksheet*.

2.5.3 Prices & Emission factors – Tab

He	at Producers and Heat Storage Adding Parameters Prices & Emission fac	ctors Profiles Load Individual Data	uuu
#	energy carrier pr	prices(EUR/MWh)	emission factor [tCO2/MWh]
	ambient heat 0	0	1
	I electricity N	NaN	0.8
	2 gas. Biomass 6	62	1
	gas/oil 4	47	0
	4 natural gas 34	30	0
	5 straw 2	22	1
	è various 2'	20	1
	7 waste 5	5	0.8
4	1		•

2.5.3.1 Short Description:

In this Tab, you can set prices and emission factors for different energy carriers. These prices are used to calculate the short run marginal costs.

These parameters can also be changed via *uploading*. Therefor you have to create an excel sheet with the structure as described *here*. Then the parameters must be specified in the *prices and emmision factors worksheet*. With the uploading method, you can create your own energy carriers (max. 13). If you create new ones don't forget to specify the new names to your heat generators in the *Energy Carrier worksheet*.



2.5.4 Radiation – Tab

2.5.4.1 Short Description:

- In this Tab, you can select (*Country-Year* drop-down-box) a predefined or a custom radiation profile with which you want to run the Application.
- If you have created your own profile with the *Load Individual Data Tab* the profile will show up in *Country-Year* drop-down-box (*Caution please*).
- The Unit of the profile is W/m^2 and the model use this profile for the solar thermal power plants. For hours where the radiation is larger than 1000 W/m² the plant works with it peak capacities installed.

You have the opportunity to make **reversible* modifications on the profile:

- you can set an offset (every value of the profile will be added by the offset value),
- you can set the whole profile to a constant value
- you can scale the profile (multiplication by a factor)
- or you can use the mean value as constant profile.

*By reversible we mean e.g. if you check the use mean value checkbox and uncheck again you will get your profile back (see picture below), the same applies if you set a constant value and then delete this value you will get the profile back, see in contrast the irreversible *modification tool* in the *Load Individual Data - Tab*).





2.5.5 Temperature – Tab

2.5.5.1 Short Description:

- In this Tab, you can select (*Country-Year* drop-down-box) a predefined or a custom temperature profile with which you want to run the Application.
- If you have created your own profile with the *Load Individual Data Tab* the profile will show up in *Country-Year* drop-down-box (*Caution please*).
- The Unit of the profile is °C and the model use this profile for the heat pumps. For hours where the temperature is smaller than 0°C the heat pumps don't work.
- You have the opportunity to make reversible modifications on the profile (details see here).

2.5.6 Electricity price / Sale Electricity price - Tab

Process to assigning a sale-/or electricity price profile



2.5.6.1 Short Description:

- In this Tabs, you can select (*Country-Year* drop-down-box) a predefined or a custom sale-/electricity price profile and then assign it to a generator (*Add to* drop-down-box) by pressing the √ Button *.
- If you have created your own profile with the *Load Individual Data Tab* the profile will show up in *Country-Year* drop-down-box (*Caution please*).
- The Unit of the profile is €/MWh and the model uses this for multiple purposes, e.g.:
 - If the energy carrier is electricity this influences the short run marginal costs
 - If your generator produces electricity this affects the revenues
- Also, here you have the opportunity to make reversible modifications on the profile (details see here).

*Caution: It is important to press the \checkmark - Button, because only so changes take effect: e.g. Let's say we want to change the **default** electricity price (see picture above):

- 1. you select a new profile with the Country-Year drop-down-box
- 2. select Default in the Add to drop-down-box then
- 3. press the \checkmark Button,
- 4. then you will get an information in the notification section,

this is the only way to assign a price profile, otherwise the initial profile or the last set profile is used.

2.5.7 Heat Demand – Tab



2.5.7.1 Short Description:

- In this Tab, you can select (*Country-Year* drop-down-box) a predefined or a custom load profile with which you want to run the Application.
- If you have created your own profile with the *Load Individual Data Tab* the profile will show up in *Country-Year* drop-down-box (*Caution please*).
- The Unit of the profile is **MW** and the model use this profile as the hourly heat demand curve.

You have the opportunity to set the total heat consumption of one year. By this you set technically the sum of all values of the profile selected.

This means if the Set Total Demand (MWh) value changes the plot will adapt so that the sum you specified is met, also the Total Demand [MWh] value in the *Parameters Tab* will change to the value specified (and vice versa). Additionally, in the notification section you can see how the peak load changes when you change the total heat consumption (see picture above).

2.5.8 Load Individual Data – Tab

Heat Producerss and Heat Storage Adding	Parame	eters Prices & Emission factors	Profiles	Load Individual Data			
Upload External Data							
Create Data			0				
None				~			
	-			(4)			1
# Value					÷	Set Sum of all values	
					2	-	
					09	Set a Offset	
3					Ð	-	(5)
					-	Set to a Constant Value	
						-	
						Scale: 1	
						Use mean value	1
	aine					Add to	1
	2					Radiation	
						Add To Heatgenerator	
						None	୲ୄ
						Set a name for your Data	
						individual	
						√ Save	
	-		Tin	ne in hours			

2.5.8.1 Short Description:

2.5.8.1.1 Upload External Data – Button

Pressing this button will enable you to upload your own data

2.5.8.1.2 Create Data – Tools

Here you can create random data. You can choose between three distributions

- 1. Dirichlet Distribution
- 2. Normal Distribution
- 3. Linear Distribution

2.5.8.1.3 Table

The values of the uploaded data or the created distribution are shown here. You can also change specific values inside the table.

2.5.8.1.4 Plot Area

Here a line plot of the values from the table is shown. With the toolbar at the right sight of the plot area you can inspect the data in more detail.

2.5.8.1.5 Modification Tools

You have the opportunity to modify the data with these tools, e.g. set the sum of all values, set an offset, scale, etc.

2.5.8.1.6 Saving Tools

After loading your custom data, or creating a distribution you can choose for which profile you want this dataset to be added. By Pressing the save button your data can be found at the selected profiles and can be used by selecting it with the name you specified.

It is also possible to add your own thermal efficiency series to heat generators.

2.5.8.2 Long Description:

2.5.8.2.1 Upload External Data

Upload External Data

When you click on this button you will get a pop up window open, where you can select your file with the desired values. Information regarding the progress are shown in the notification section. The file you upload must have following structure:

- 1. It has to be either a .xlsx or a .csv data
- 2. the files **must** have the **structure** as below (left: *.xlsx*, right:*csv*)

A		
header_name	-	
3.142	1	header_name
2.718	2	3.142
6.673	3	2.718
6.626	4	6.673
9.798	5	6.626
	6	9.798
413.5	8760	
8.854	8761	8.854
	A header_name 3.142 2.718 6.673 6.626 9.798 413.5 8.854	A header_name 3.142 1 2.718 2 6.673 3 6.626 4 9.798 6 413.5 8760 8.854 8761

3. you have to specify 8760 values and a header name

4. for *.xlsx* only the values of the **first worksheet** will be **uploaded**

An example of a successful upload can be seen in the picture below.



2.5.8.2.2 Create Data Tool

This part of the user interface enables you to create random data. For this purpose, following distributions are available

Create Data	
None	~
Dirichlet Distribution	
Normal Distribution	
Linear Distribution	
None	

2.5.8.2.2.1 Dirichlet Distribution:

To use this distribution, you have to specify the sum $\left\{:\Sigma\right\}$ - input widget. It gives you random numbers so the sum you specify is met. An example with sum $\left\{:\Sigma\right\}$ =10 is shown below.



2.5.8.2.2.2 Normal Distribution

Another option to create random number is the gaussian-normal-distribution. To use this, you have to specify a mean value (sigma $\$) and standard deviation from that value my $\$. Below is a normal distribution with $\$) and standard deviation from that value my $\$ must be a normal distribution with $\$ normal distribution. To use this, you have to specify a mean value (sigma $\$) and standard deviation from that value my $\$. Below is a normal distribution with $\$ normal distribution. To use this, you have to specify a mean value (sigma $\$) and standard deviation from that value my $\$.



2.5.8.2.2.3 Linear Distribution

We this option you can create 8760 number that are linear distributed beginning from start and ending with stop. An example with start=-10 and stop=100 is shown below.





2.5.8.2.3 Table and Plot Area

The values of the uploaded data or the created distribution are shown here in tabular and graphical form. You can also change specific values inside the table, in that case the cell you are editing become yellow and the graph is blurred. After editing press, the reset button on the toolbar to remove the blur.

2.5.8.2.4 Modification Tools

Set Sum of all values
-
Set a Offset
-
Set to a Constant Value
-
Scale: 1
Use mean value

You have the opportunity to modify the data with these tools, e.g. set the sum of all values, set an offset, scale, etc. *.

**Caution: This permanently change the values in the table!* (It works with the direct values and therefore it is an irreversible process e.g. if you check the use the mean value checkbox and then unchecked again you will not get your profile back see picture below, you have to upload or create your data again)



Irreversible process of the modification tool in the Load Individual Data Tab

2.5.8.2.5 Saving Tools



After loading your custom data, or creating a distribution you can choose for which profile you want this dataset to be added.

ŀ	Add to	
	n_th/COP	-
	Radiation	
1	Temperature	
	Electricity price	
	Sale Electricity price	
	Heat Demand	
l	n_th/COP	

By Pressing the save button your data can be found at the selected profiles (Add to) Tab and can be used by selecting it with the name you specified *.

*Caution: The name of the data will always be terminated by the string _1 after saving (e.g. if you specify individual as your name and saved it to Radiation, you will find your profile in the Radiation Tab by the name individual_1

It is also possible to specify a time specific thermal efficiency for a heat generator (or COP for heat pumps).

To use this feature, you have to select in the Add To-drop down button n_th/COP and then select the heat generator (Add To Heatgenerator) which you like to add your custom thermal efficiency. Then you press save and you get an information in the notification section. The picture below shows an example.

Add to	
n_th/COP	~
Add To Heatgenerator	
Air Heat Pump	~
Set a name for your Data	
Set a name for your Data individual	
Set a name for your Data individual	

chapter $\mathbf{3}$

Indices and tables

- genindex
- modindex
- search